
## **Mandatory Site Rules**

- 1. When using forklift in external stockyard/ carpark, utilise internal pedestrian controls to ensure a complete 100% exclusion zone is set up. Shunting is not permitted.
- 2. When using forklift inside of stock room utilise internal pedestrian controls as to ensure a complete 100% exclusion zone is set up.
- 3. Driver zone is Minimum 1.5m from exclusion zone and is marked on the ground or with signage. Not permitted in cab.
- 4. Please Note: All equipment & signage MUST be installed as per the plan. No deviation permitted.
- 5. All Team Members are required to have completed the Traffic Management Know Your Plan Module in MyLearning.
- 6. While Rubbish / Paper Bins are being picked up, no Team Member to be on the forecourt/yard or access area.
- 7. All TMP activities are to be carried out as per the TMP SOP and TMP Business Rules.

#### **Site Descriptions**

Site Details: Strip Mall
Off Load Area: Yard
Truck Unloading: Double Side

Access: Open to Both (Pedestrian and other Traffic)





#### **CAD PLANS**

6 CHELSEA AVENUE
AUCKLAND
NEW ZEALAND 1062
+6421 108 0460
OFFICE@CADPLANS.CO.NZ

## SAMPLE PLAN ONLY

Date: 07/10/2022

Version No: 001

Drawn: D. Bon

Checked: A. De Silva

Scale: Not Applicable

Legends:

Forklift Access

1 0111111171000

10km/h Speed

Forklift Operation

Forklift Operation

Drive Safety Zone

Hi-Vis Must be Worn at all times



10

### **General Notes:**

1. Driver must make contact with Warehouse Team.

2. Driver must have hazard lights on.

3. Driver must follow the speed limit and use designated driver safety box during

loading and unloading.


4. Driver requires confirmation to leave safe zone.

5. Driver paperwork - only to be completed in safety zone.

6. Proceed to exit - Driver Exit Point



Plan 1 - Truck/Courier offload / Forklift use with Exclusion Zone / Internal Controls





### **CAD PLANS**

6 CHELSEA AVENUE AUCKLAND NEW ZEALAND 1062 +6421 108 0460 OFFICE@CADPLANS.CO.NZ

## **SAMPLE PLAN ONLY**

Date: 07/10/2022

Version No: 001

Drawn: D. Bon

Checked: A. De Silva

Scale: 1:200 @ A3 Paper

Legends:

Forklift Access

10km/h Speed

Forklift Operation

Drive Safety Zone

Hi-Vis Must be Worn at all times




10

- 1. Driver must make contact with Warehouse Team.
- 2. Driver must have hazard lights on.
- 3. Driver must follow the speed limit and use designated driver safety box during loading and unloading.
- 4. Driver requires confirmation to leave safe zone.
- 5. Driver paperwork only to be completed in safety zone.
- 6. Proceed to exit -**Driver Exit Point**



Plan 2 - Forklift use with Exclusion Zone / Internal Controls





### **CAD PLANS**

6 CHELSEA AVENUE AUCKLAND NEW ZEALAND 1062 +6421 108 0460 OFFICE@CADPLANS.CO.NZ

## **SAMPLE PLAN ONLY**

Date: 07/10/2022

Version No: 001

Drawn: D. Bon

Checked: A. De Silva

Scale: 1:200 @ A3 Paper

Legends:

Forklift Access

10km/h Speed

Forklift Operation

Drive Safety Zone

Hi-Vis Must be Worn at all times




10

### **General Notes:**

- 1. Driver must make contact with Warehouse Team.
- 2. Driver must have hazard lights on.
- 3. Driver must follow the speed limit and use designated driver safety box during loading and unloading. 4. Driver requires
- confirmation to leave safe zone.
- 5. Driver paperwork only to be completed in safety zone.
- 6. Proceed to exit -**Driver Exit Point**



Plan 3 - Internal Controls





### CAD PLANS

6 CHELSEA AVENUE
AUCKLAND
NEW ZEALAND 1062
+6421 108 0460
OFFICE@CADPLANS.CO.NZ

## SAMPLE PLAN ONLY

Date: 07/10/2022

Version No: 001

Drawn: D. Bon

Checked: A. De Silva

Scale: 1:150 @ A3 Paper

Legends:

Forklift Access

10km/h Speed

Limit
Forklift Operation

Area

Drive Safety Zone

Hi-Vis Must be

Hi-Vis Must be Worn at all times



10

- Driver must make contact with Warehouse Team.
   Driver must have
- hazard lights on.
- 3. Driver must follow the speed limit and use designated driver safety box during loading and unloading. 4. Driver requires
- confirmation to leave safe zone.
- 5. Driver paperwork only to be completed in safety zone.
- 6. Proceed to exit Driver Exit Point

